



Qwickshine Pads

February 2014

Process for the application of Qwickshine Pads :

<u>Step</u>	<u>Description</u>
No 1 #400 Grit	For the restoration of heavily worn stone and concrete floors. Effectively removes scratches and stains on the floors and cleans dirty surfaces.
No 2 #800 Grit	For the removal of fine scratches on floors and leave a clean surface for the next step.
No 3 #1500 Grit	This step prepares the floor for polishing. Concrete floors start to shine.
No 4 #3000 Grit	This step polishes concrete floors. Granite and marble floors are prepared for final polish.
No 5 Buff	Final step that brings floors to a mirror finish. You can maintain a high gloss finish without any wax or chemicals. Suitable for high speed polishing of polished concrete, granite, marble and terrazzo.

Unit 14 Northlake Industrial Business Park
52 Malcolm Moodie Crescent
Jet Park

PO Box 75794
Gardenvue
2047
VAT #: 4390201996

Tel: 0861 75 75 75
Fax: 011 552 8312
Int Tel: +27 (0) 11 552 8310